

Chain and Roller to Dual Belt Conveyor Conversion Process

This document will walk through the process of converting a chain and roller system to a dual belt. Please notify Tommy Car Wash Systems prior to converting your site.

1. Close wash for planned downtime, typically 1-2 weeks.



2. Remove floor and excavate according to Belt Pit Plan, leaving wash equipment in place.



3. Pour concrete on new pit floor .



4. Allow concrete time to cure.



5. Pour side wall



6. Install new Tommy Transporter Belt Conveyor and reopen car wash.

