



Tommy Car Wash Systems | 581 Ottawa Ave. | Holland, MI 49423 | [tommycarwash.com](http://tommycarwash.com)

---

## Blower Housing Installation Instructions

Step 1: Remove intake screen or blast gate from old housing along with the blower nozzle. These items will all need to be reused on the new housing.

Step 2: Remove old blower housing - there will be screws that attach the housing to the back plate - loosen screws and remove housing.

Step 3: Mount new housing to the back plate. The new housing will have a steel ring on the inner ring of the housing, this is the back side to be mounted to the back plate. New hardware is provided.



Steel ring to be mounted to the back plate of blower.

---

Step 4: Mount intake screen or blast gate - you will need to reuse the hardware. This will get mounted to the side without the steel ring.

Step 5: Install blower nozzle - reuse existing nozzle and install onto housing.

Step 6: Install nozzle pins - we have provided 2 bolts that will need to be installed through the nozzle and housing.

- Drill hole
- Slide bolt in
- Tighten washer and nut
- Make sure to install as high up on the nozzle as possible this should go through the nozzle and housing.



Nozzle is not pictured – make sure these bolts go through both the nozzle and housing.

This is to prevent any debris from exiting the nozzle.

---

If you have any questions, please reach out to either  
Client Services or Equipment Support

Client Services - 616-795-4893

[clientservices@tommycarwash.com](mailto:clientservices@tommycarwash.com)

Equipment Support - 616-795-4893

[support@tommycarwash.com](mailto:support@tommycarwash.com)

---