

Tuesday: Day 3

page 1 of 2
page 2 of 2

1

2

3

4


5


6

7

Combo 2

Clean Combo 2

 30 minutes

 1 Team Member



TOOLS:


- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder (*use spotter*)
- Blue Scotch Brite pad
- Degreaser
- Welding tip cleaner




STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Using brush and Tommy Brite, clean all stainless Arches, tubing, cross members, Wrap arms, Wrap drop downs, Stub Shafts, air cylinders, shocks, Rocker arms, Mitter Basket and Ladder Rack.
5. Use a ladder to access the Ladder Rack (*use spotter*).
6. Clean the top of Ladder Rack and Arch using the long handle brush and Tommy Brite solution.
7. Degreaser may be needed for Flange Bearing, Pillow Block Bearings, and Ladder Rack.
8. Use blue Scotch Brite pad for excessive build up.
9. Use welding tip cleaner to clean out all nozzles.
10. Use Bay Gun or Fire Gun to rinse of the Arch, Ladder Rack, and signage.
11. Inspect Foamer inserts and replace if necessary.
12. Rinse all equipment used return to assigned location.

Red Balls Trash Receptacle

 30 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Tommy Brite
- Blue Scotch Brite Pad
- Bay Gun
- Garden Hose



STEPS:

1. Empty the trash can first, and then gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with cleaner using hose attached to Maintenance POD.
4. Dip Blue Scotch Brite Pad into bucket and scrub the entire ball from top to bottom in circular motion.
5. Rinse with a garden hose, making sure you rinse any debris/stains from the sidewalk.
6. Bring the inserts inside, wash them down with the Blue Scotch Brite Pad.
7. Rinse the inserts with the Bay Gun. Make sure that you rinse the floor of any debris/stains.
8. Replace inserts back into the trash receptacle balls.
9. Rinse all equipment used return to assigned location.

Tuesday: Day 3

page 1 of 2
page 2 of 2

1

Clean Walls under the windows and Vents

15-20 minutes

1 Team Member



TOOLS:

- P.P.E.
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder (spotter needed)



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Scrub all walls and vents from beginning of Combo 2 up to rinse area. (Using an extendable handle with brush will allow you to reach the vents and ceiling).
5. Rinse using Bay Gun or Fire Hose.
6. Utilize ladder (with spotter) if necessary.
7. Rinse all equipment used and return to assigned location.

2

Clean Detergent Stainless Steel Supply Lines

15-20 minutes

1 Team Member



TOOLS:

- P.P.E.
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder (use spotter)
- Blue Scotch Brite Pad



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD. Use brush and Tommy Brite to clean stainless steel lines that go from Detergent POD to Ladder Rack.
4. Use ladder (with spotter) if needed.
5. Rinse all equipment used return to assigned location.

3

Clean Pit Grates

20-30 minutes

1 Team Member



TOOLS:

- P.P.E.
- Bucket
- Hard bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Remove Pit Grates from Combo 2 to High Pressure Rinse.
5. Spray the grates, and edges they rest on, with the Bay Gun.
6. Using the brush, soak Grates with Tommy Brite.
7. Use high pressure Bay Gun to remove debris that the cleanser broke down.
8. Replace Pit Grates.
9. Rinse all equipment used return to assigned location.

4

Clean and Flush Pit

30 minutes

2 Team Members



TOOLS:

- P.P.E.
- Buckets
- Shovel
- Bay gun
- Fire Hose
- Scotch Brite pad



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Remove Pit Grates from Combo 2 to High Pressure Rinse.
4. Use Fire Hose to flush Pit floor to nearest drain, flush under the Belt, and all V-throughs.
5. Use the shovel and a bucket/s to scoop up dirt and debris and dispose of according to state guidelines. Multiple buckets may be filled during this process.
6. Using the Fire Hose, do a final Rinse.
7. Replace Pit Grates.
8. Rinse all equipment used return to assigned location.

5

6

7

Wednesday: Day 4

page 1 of 3

page 1 of 3

page 1 of 3

1

2

3

4


5


6


7


Body Wax - High Pressure Rinse - Tommy Guard

Clean Walls under the windows and Vents

 15-20 minutes


 1 Team Member


-  **TOOLS:**
- P.P.E.
 - Bucket
 - Soft bristle brush
 - Bay gun (uses less water at a higher pressure) or Fire Hose
 - Tommy Brite
 - Ladder (spotter needed)


-  **STEPS:**
1. Gather all needed equipment.
 2. Put on P.P.E.
 3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
 4. Scrub all walls and vents from beginning of Body Wax up to Tommy Guard (Using an extendable handle with brush will allow you to reach the vents and ceiling).
 5. Rinse using Bay Gun or Fire Hose.
 6. Utilize ladder (with spotter) if necessary.
 7. Rinse all equipment used return to assigned location.

Clean Maintenance POD


 15-20 minutes


 1 Team Member


-  **TOOLS:**
- P.P.E.
 - Stainless steel cleaner
 - Soft cloth


-  **STEPS:**
1. Gather all needed equipment.
 2. Put on P.P.E.
 3. Using stainless steel polish and a soft cloth rag, clean and polish all stainless steel on the Detergent POD, Maintenance POD, and Hydraulic POD (if applicable).
 4. After polishing, use a clean soft cloth to remove any excess polish on the PODs to eliminate streaking.
 5. Rinse all equipment used return to assigned location.

For Hydraulic Only: Hydraulic Stainless Steel Supply Lines & Hoses

 20-30 minutes

 1 Team Member

-  **TOOLS:**
- P.P.E.
 - Bucket
 - Soft bristle brush
 - Rag
 - Bay gun (uses less water at a higher pressure) or Fire Hose
 - Tommy Brite
 - Ladder (use spotter)
 - Blue Scotch Brite Pad

-  **STEPS:**
1. Gather all needed equipment.
 2. Put on P.P.E.
 3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
 4. Use a rag and Tommy Brite to clean stainless steel lines that go from Hydraulic Tank to Ladder Rack. Use ladder (with spotter) if needed.
 5. Rinse all equipment used return to assigned location.

Wednesday: Day 4

page 1 of 3

page 1 of 3

page 1 of 3

1

2

3


4


5

6

7

Clean Body Wax Arch

 15-20 minutes

 1 Team Member



TOOLS:


- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder (use spotter)
- Blue Scotch Brite pad




STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Using brush and Tommy Brite, clean all signs, sides, lights, and Arch, including the top, Connecting Ladder Rack, and stainless tubing.
5. Clean Wax Bar (inside and out) using high pressure gun.
6. Use a ladder to access the Ladder Rack (use spotter).
7. Clean the top of Ladder Rack and Arch using the long handle brush and Tommy Brite solution.
8. Use blue Scotch Brite pad for excessive build up.
9. Use Bay Gun or Fire Gun to rinse of the Arch, Ladder Rack, and signage.
10. Inspect foamer inserts, and replace if necessary.
11. Rinse all equipment used return to assigned location.

Clean High Pressure Rinse Arch

 20-25 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder
- Blue Scotch Brite pad
- Welding tip cleaner



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Using brush and Tommy Brite, clean all signs, sides, lights, and Arch, including the top, Connecting Ladder Rack, and stainless tubing.
5. Use a ladder to access the Ladder Rack (use spotter).
6. Clean the top of Ladder Rack and Arch using the long handle brush and Tommy Brite solution.
7. Use Blue Scotch Brite pad for excessive build up.
8. Remove all Detergent spray nozzles and visually check for blockage.
9. Clean the rinse bar (inside and out) with the high pressure gun.
10. Use the welding tip cleaner to clean clogged nozzles.
11. Replace clean nozzles.
12. Use Bay Gun or Fire Gun to rinse of the Arch, Ladder Rack, and signage.
13. Rinse all equipment used return to assigned location.



Guests, not customers.

Wednesday: Day 4

page 1 of 3

page 1 of 3

page 1 of 3

1

2

3

4

5

6

7

Clean Tommy Guard Arch



20-25 minutes



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder
- Blue Scotch Brite pad
- Welding tip cleaner



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Using brush and Tommy Brite, clean all signs, sides, lights, and Arch, including the top, Connecting Ladder Rack, and stainless tubing.
5. Use a ladder to access the Ladder Rack (use spotter).
6. Clean the top of Ladder Rack and Arch using the long handle brush and Tommy Brite solution.
7. Use Blue Scotch Brite pad for excessive build up.
8. Remove all Detergent spray nozzles and visually check for blockage.
9. Use the welding tip cleaner to clean clogged nozzles.
10. Replace clean nozzles
11. Use Bay Gun or Fire Gun to rinse of the Arch, Ladder Rack, and signage.
12. Inspect foamer inserts, and replace if necessary.
13. Rinse all equipment used return to assigned location.

Clean Pit Grates



20-30 minutes



1 Team Member



TOOLS:

- P.P.E.
- Bucket
- Hard bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Remove Pit Grates from Combo 2 to High Pressure Rinse.
5. Spray the grates, and edges they rest on, with the Bay Gun. Using the brush, soak Grates with Tommy Brite.
6. Use high pressure Bay Gun to remove debris that the cleanser broke down.
7. Replace Pit Grates.
8. Rinse all equipment used return to assigned location.

Clean and Flush Pit



30 minutes



2 Team Member



TOOLS:

- P.P.E.
- Buckets
- Shovel
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Scotch Brite pad



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Remove Pit Grates from Combo 2 to High Pressure Rinse.
4. Use Fire Hose to flush Pit floor to the nearest drain, flush under the Belt, Take Up Assembly and all V-throughs.
5. Use the shovel and a bucket(s) to scoop up dirt and debris and dispose of according to state guidelines. Multiple buckets may be filled during this process.
6. Use high pressure rinse to remove all remaining debris on the Belt, piping for Belt Flush, floor and remaining equipment within this section.
7. Replace Pit Grates
8. Rinse all equipment used return to assigned location.

Thursday: Day 5

page 1 of 2
page 2 of 2

Drying Agent Arch to Blower Room Wall

Clean Walls/Vents

15-20 minutes



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Scrub all Walls/Vents from the Rinse Arch to the Blower Room Wall.
5. Using an Extendable Handle with the Brush will allow you to reach the Ceiling.
6. Rinse using the Bay Gun or Fire Hose.
7. Rinse all equipment used return to assigned location.

Clean Drying Agent Manifold

20-25 minutes



1 Team Member



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder (**Spotter needed when on Ladder*)
- Welding Tip Cleaner



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Using brush and Tommy Brite, clean all sides, including top of Arch, Connecting Ladder Rack, and stainless tubing.
5. Use the ladder to clean Ladder Rack and top of Arch.
6. Use Blue Scotch Brite pad for excessive build up.
7. Using the Welding Tip cleaner, clean out all nozzles.
8. Use Bay Gun to rinse off Detergents.
9. Rinse all equipment used return to assigned location.



1

2

3

4

5

6

7

Thursday: Day 5

page 1 of 2
page 2 of 2

1

Clean Spot Free Rinse Arch



20-25 minutes



1 Team Member



TOOLS:

- P.P.E.
- Bucket
- Soft bristle brush with long handle
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite
- Ladder (*spotter needed when on ladder)
- Scotch Brite Pad
- Welding Tip Cleaner



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Using Brush and Tommy Brite, Clean all sides, including top of arch, connecting ladder rack and stainless tubing
5. Use the Ladder to clean Ladder Rack and top of Arch
6. Use a Scotch Brite Pad for excessive build up
7. Using the Welding Tips, clean out all nozzles
8. Use Bay Gun to rinse off Detergents
9. Rinse all equipment used return to assigned location.

2

Clean Pit Grates



10-15 minutes



1 Team Member



TOOLS:

- P.P.E.
- Hard bristle brush
- Bucket
- Tommy Brite
- Scotch Brite Pad
- Bay Gun



STEPS:

1. Gather all needed equipment
2. Put on P.P.E.
3. Remove Pit Grates in Tommy Brite using a brush
4. High Pressure edge where Pit Grates sits
5. Use a Scotch Brite Pad for excessive build up
6. High Pressure all Pit Grates
7. Put Pit Grates back in place
8. Rinse all equipment used return to assigned location.

3

Clean and Flush Pit



30 minutes



2 Team Member



TOOLS:

- P.P.E.
- Buckets
- Shovel
- Scotch Brite Pad
- Bay Gun
- Fire Hose



STEPS:

1. Gather all needed equipment
2. Put on P.P.E.
3. Remove Pit Grates
4. Using the fire hose, flush pit floor to the nearest drain, flush under the belt, take-up assembly, and V-troughs
5. Use the shovel and a bucket(s) to scoop up dirt and debris and dispose of according to state guidelines. Multiple buckets may be filled during this process.
6. Using the Fire Hose, do a final rinse
7. Use a Scotch Brite Pad or Brush for excessive build up
8. High Pressure all Pit Grates
9. Put Pit Grates back in place
10. Rinse all equipment used return to assigned location.

4

5

6

7


Friday: Day 6


page 1 of 2
page 2 of 2

1

Blower Room

Clean Exit Garage Door

 15-20 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Tommy Brite
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Soft Cloth
- All Purpose Cleaner




STEPS:


1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Set Doors to Manual to eliminate them from going up and down.
5. Scrub both sides of the door using a Brush and Cleaning Solution.
7. Rinse using the Bay Gun or Fire Hose.
8. Clean the Clear Plastic using All Purpose Cleaner and a damp cloth.
9. Rinse one final time.
10. Set doors to Auto to allow for proper drying.
11. Rinse all equipment used return to assigned location.

2

3

Clean Walls/Vents

 15-20 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Bay gun (uses less water at a higher pressure) or Fire Hose
- Tommy Brite



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
4. Scrub all Walls/Vents in the Blower Room.
5. Using an Extendable Handle with the Brush will allow you to reach the ceiling.
6. Rinse using Bay Gun or Fire Hose.
7. Rinse all equipment used return to assigned location.

4

5

6

7



Friday: Day 6

page 1 of 2
page 2 of 2

1

Clean Blowers and Arches

30-45 minutes

2 Team Member



- TOOLS:**
- P.P.E.
 - Brush with Long Handle
 - Bucket
 - Bay gun (uses less water at a higher pressure) or Fire Hose
 - Ladder (use spotter)
 - Tommy Brite
 - Scotch Brite pad
 - Soft cloth



- STEPS:**
1. Gather all needed equipment.
 2. Put on P.P.E.
 3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
 4. Using brush and Tommy Brite, Clean all Blowers (Housing, Intakes, Blast Gates), arches, including top of arch, connecting ladder rack and stainless tubing.
 5. Use a ladder to clean Ladder Rack and top of arch (use spotter).
 6. Use a Scotch Brite Pad for excessive build up.
 7. Use Bay Gun or Fire Gun to rinse off Detergents (Avoid spraying blue motors).
 8. Ensure that all Stainless Steel is clean and looking new (Tip: Magic Erasers keep Intakes super clean and shiny).
 9. Do NOT use hard bristle brush on Exit Module (Wipe clean with damp soft cloth with water and then wipe again with dry cloth).
 10. Rinse all equipment used return to assigned location.

2

Clean Pit Grates

10-15 minutes

1 Team Member



- TOOLS:**
- P.P.E.
 - Hard Bristle Brush
 - Bucket
 - Bay gun (uses less water at a higher pressure) or Fire Hose
 - Tommy Brite
 - Scotch Brite pad



- STEPS:**
1. Gather all needed equipment.
 2. Put on P.P.E.
 3. Fill bucket with Tommy Brite using hose attached to Maintenance POD.
 4. Remove Pit Grates in the Blower Room and spray off with the Bay Gun.
 5. Soak Pit Grates in Tommy Brite using a brush.
 6. High Pressure edge where Pit Grates Sit.
 7. Use Scotch Brite pad for excessive build up.
 8. High Pressure all Pit Grates.
 9. Put Pit Grates back in place.
 10. Rinse all equipment used return to assigned location.

3

4

Clean and Flush Pit

30 minutes

2 Team Members



- TOOLS:**
- P.P.E.
 - Buckets
 - Shovel
 - Bay gun
 - Fire Hose
 - Scotch Brite pad



- STEPS:**
1. Gather all needed equipment.
 2. Put on P.P.E.
 3. Remove Pit Grates.
 4. Using the fire hose, flush pit floor to the nearest drain, flush under the belt, take-up assembly, and V-troughs.
 5. Use the shovel and a bucket(s) to scoop up dirt and debris and dispose of according to state guidelines. Multiple buckets may be filled during this process.
 6. Using the Fire Hose, do a final rinse.
 7. Use a Scotch Brite Pad or Brush for excessive build up.
 8. High Pressure all Pit Grates.
 9. Put Pit Grates back in place.
 10. Rinse all equipment used return to assigned location.

5

6

7


Saturday: Day 7


page 1 of 2
page 2 of 2

1

Exterior

Exterior Windows/Vents

 30-40 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Brush with long handle
- Bucket
- Soft bristle brush
- Potable power washer
- Hose
- Tommy Brite or window cleaner
- Gas (see user manual)





STEPS:

1. Gather all needed equipment.
2. Put on p.P.E.
3. Fill bucket with tommy brite using hose attached to Maintenance pod.
4. Scrub all exterior windows passenger/drivers side and doors.
5. Using an extendable handle with the soft-cloth brush will allow You to reach the whole window/vent.
6. Rinse using a portable power washer (refer to user manual for operating instructions).
7. Squeegee excess water from windows.
8. Allow for windows to air dry. Spot check for streaking after dry
9. Rinse all equipment used return to assigned location.

2

Pay Lane and Stack Concrete

 30-40 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Portable Power Washer
- Surface Cleaner Attachment
- Hose
- Gas (see user manual)





STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Only perform this task while slow, we do not want to interrupt service for our Guests.
4. Ensure power washer has gas in it.
5. Using power washer and surface cleaner attachment clean all lanes. Do one at a time to avoid disturbing production.
6. Refer to power washer user manual for operating instructions.
7. Rinse dirty water down the closest storm drain.
8. Rinse all equipment used return to assigned location.

3

Entrance/Exit Lane Concrete

 30-40 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Portable Power Washer
- Surface Cleaner Attachment
- Hose
- Gas (see user manual)



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Only perform this task while slow, we do not want to interrupt service for our Guests.
4. Ensure power washer has gas in it.
5. Using power washer and surface cleaner attachment clean all lanes. Do one at a time to avoid disturbing production.
6. Refer to power washer user manual for operating instructions.
7. Rinse dirty water down the closest storm drain.
8. Rinse all equipment used return to assigned location.

4

5

6


7


Saturday: Day 7

page 1 of 2
page 2 of 2

Exterior

Vacuum Area Concrete

 30-40 minutes

 1 Team Member



TOOLS:

- P.P.E.
- Portable Power Washer
- Surface Cleaner Attachment
- Hose
- Gas (see user manual)



STEPS:

1. Gather all needed equipment.
2. Put on P.P.E.
3. Fill bucket with Tommy Brite using hose attached to Maintenance Pod.
4. Using brush and Tommy Brite, clean all signs, sides, lights, and Arch, including the top, Connecting Ladder Rack, and stainless tubing.
5. Use a ladder to access the Ladder Rack (use spotter).
6. Clean the top of Ladder Rack and Arch using the long handle brush and Tommy Brite solution.
7. Use blue Scotch Brite pad for excessive build up.
8. Use Bay Gun or Fire Gun to rinse of the Arch, Ladder Rack, and signage.
9. Inspect Foamer inserts and replace if necessary.
10. Rinse all equipment used return to assigned location.



1

2

3

4

5

6

7