

LPR PC

HMI PC

GWC Network Switch

NVR Camera Switch

LPR Camera Switch

Patch Panels*

KVM Display

CB1**

Lane Controller

Spectre Router***

Mac Mini

GWC Router****

NVR Computer

Battery Backup

Battery Backup

*Patch Panels are connections between equipment

**CB1 or Circuit Breaker 1 is used to reset the lane controller

***Spectre routers are blue and mounted on the back of the cabinet

****GWC router can be a cisco, edge, or linksys router. Most recent routers are edge