


April 1, 2020

Sew Eurodrive Gearbox Oil Maintenance

Belt drive systems incorporate a SEW Eurodrive gear box system that translates the electric motor power to extreme torque used to drive the belt conveyor. The gear box comes prefilled with oil however we always suggest double checking to ensure the gear box has been filled.

The oil in the gear box should be changed every 6 months to 1 year depending on wash volume. You should be using Shell Omala S2 GX 220.

Any abnormal pulsating of the belt, or abnormal noise from the drive end section would suggest checking the oil level or changing the oil in the gearbox.



Note: Please Refer to Sew Eurodrive Manual for additional instructions.

9	Lubri	cants	74
	9.1	Lubricant table	74
	9.2	Lubricant fill quantities	77